



AUDIO HQ SPIRIT  
**BOOST** **/// RUN**

TWS SPORT EARPHONES

**MANUAL**

**EN**  
ENGLISH


**ES**  
ESPAÑOL

[www.foxbox.com.ar](http://www.foxbox.com.ar)




## Wireless 5.0 more compatible

Compatible with IOS and Android smartphones



- IOS
- android



### **Packing list:**

- Bluetooth earbuds
- Earbuds power box
- USB charging cable
- Packaging with User's Manual QR



## Product specifications

Bluetooth connection name: FOXBOX | Run  
Bluetooth version: 5.0  
Power Input: DC 5V  
Earbud battery capacity: 3.7V/ 40mAh  
Call/ play time: about 5/6 hours  
Charging time: about 60 minutes  
Charge box battery capacity: 3.7V/ 350 mAh  
Bluetooth support: A2DP  
Audio decoding mode: SBC  
Microphone sensitivity: -42 +3dB  
Speaker specifications: 32Ω + 15%  
Working frequency: 2480 GHz

## Pairing

When you take the earbuds out of the charging box, the red and blue lights flash alternately. If this does not happen, connect the charging box to charge the battery.

To use the earbuds, turn on the bluetooth of the device you want to connect and search for the "FOXBOX | Run" earbuds.




*Note: If the earbuds is not connected within 1 minute, it will enter standby mode.*

After using the earbuds, put them in the charging box and they will turn off automatically.

To use the earbuds again, remove it from the charging case and it will automatically pair with the device.

## Functions

1. Power on/off: Press for about 3 sec.
2. Voice Assistant: Press for about 2 sec the function button on either earbud.
3. Play/Pause: press the function button of any earbud.
4. Next/Last song: press 3 times the function button of any earphone to skip songs and 2 times to go back to the previous song during music playing.
5. Answer calls: press the function button of any earbud to answer when you have an incoming call.
6. End call: press the function button of any earphone to end the call.
7. Reject call: long press the function button of any earphone when you want to reject an incoming call.



*Note: Volume control is done through the paired device.*


## Charging scheme

### Battery duration

Call/ Play: about **5/6** Hs

Standby: about **100**

Charging box:  
Charges: **4**



### Charging box

When charging: Blue light flashing

Full power: Blue light on and off

Charging time: about 1 hour

### Earbuds

When charging: Red light on

Full power: Red light on and off

Charging time: about 1 hour

*Note: When charging the charging box, please use the corresponding charging cable that is included*

*Special note: Please do not use more than 5V/1A fast charging charger, so as not to damage the charging box.*

## Wear schematic



Rigth




Left



## Compatibilidad inalámbrica 5.0


Compatible con smartphones IOS y Android



Izquierdo

Derecho

- IOS
- android



### Contenido:

- Auriculares Bluetooth
- Caja de carga
- Cable de carga USB
- Packaging con QR para manual

## Especificaciones del producto

Nombre de conexión de bluetooth: FOXBOX | Run

Versión bluetooth: 5.0

Entrada: DC 5V

Capacidad de batería del auricular: 3.7V/ 40mAh

Tiempo de uso continuo: aprox. 5/6 horas

Tiempo de carga: aprox. 60 minutos

Capacidad de batería de la caja de carga: 3.7V/ 350 mAh

Soporte bluetooth: A2DP

Modo de decodificación del audio: SBC

Sensibilidad del microfono: -42 +3dB

Especificaciones de los parlantes: 32Q + 15%


Frecuencia de trabajo: 2480 GHz



## Emparejamiento

Al sacar los auriculares de la caja de carga, las luces rojas y azules parpadean alternativamente. Si esto no sucede, conecte la caja de carga para cargar la batería.

Para usar los auriculares, encienda el bluetooth del dispositivo que desea conectar y busque los auriculares "FOXBOX | Run".



Luces indicadoras




*Nota: si los auriculares no se conectan en 1 minuto, entraran automáticamente en modo de espera.*

Después de usar los auriculares, colóquelos directamente en la caja de carga y se apagarán.

Para volver a usar los auriculares, simplemente retírelos de la caja de carga, se emparejarán y conectarán al teléfono automáticamente.

## Funcionalidades

1. Encendido/apagado: presione durante aprox. 3 segundos.
2. Asistente de voz: presione dos veces el botón de función de cualquiera de los auriculares.
3. Reproducir / Pausar: presione el botón de función de cualquier auricular durante la reproducción de música
4. Siguiente / Última canción: presione 3 veces el botón de función de cualquier auricular para pasar de canción y 2 veces para regresar a la anterior, durante la reproducción de música.
5. Responder llamadas: presione el botón de función de cualquier auricular para contestar cuando tenga una llamada entrante
6. Fin de la llamada: presione el botón de función de cualquier auricular para finalizar la llamada.
7. Rechazar llamada: presione el botón de función de cualquier auricular durante un instante cuando desee rechazar una llamada entrante.



*Nota: el control del volumen se realiza a través del dispositivo vinculado.*


## Esquema de carga

### Duración de batería

Uso continuo: aprox. 5/6 Hs

Sin usar: aprox. 100

Charging box: 4  
Cargas: aprox.



### Caja de carga

Al cargar: Luz azul parpadeando  
Carga completa: Luz azul encendida  
Tiempo de carga: aprox. 1 hora

### Auriculares

Al cargar: Luz roja encendida  
Carga completa: Luz roja encendida  
Tiempo de carga: aprox. 1 hora

*Nota: Al cargar la caja de carga, utilice el correspondiente cable de carga que se incluye*

*Nota especial: no utilice un cargador de carga rápida de más de 5 V/1 A para no dañar la caja de carga.*

## Esquema de uso



Derecha



Izquierda